






Optional Accessories



MOUNT



SHAPING



POWER



i To prevent damaging the lens, when lens mounted don't use a NP-F battery to power the light, but use an external power source through the DC connector.



Quick Start Guide



R300 SE
LED Ring Light

- 1 Getting Started
- 2 Functions



F&V Europe B.V.
Steenovenweg 5, 5708HN Helmond, The Netherlands
TM & © F&V All rights reserved.

For more information visit: fvlight.com

What's in the box?



1 Getting Started

1 Mounting



2 Power

Two power options

- 1 NP-F Li-ion battery
- 2 DC Φ 2.5 10-18V


3 Let's do this!

Turn the light ON

- <I> when powering through DC Jack
- <II> when using NP-F batteries



2 Functions



1 Adjust the Intensity

Use <Intensity> knob to adjust the intensity

2 * Adjust the Color Temperature (only the bi-color version)

Use <Color Temperature> knob to adjust the color temperature